

# StrikeGuard®

STRIKE VIEW SOFTWARE  
WITH E-MAIL NOTIFICATION

Strike View Software with E-mail Notification runs on a personal computer which connects to the Strike Guard Lightning Data Receiver to provide PC-based lightning data displays, audible and visual lightning alarms, and lightning data logging.

Strike View Software helps the user to categorize lightning data, analyze storm progression, and estimate the time to resume operations. Strike View expands upon the information presented by the Lightning Data Receiver.



## STRIKE VIEW DELIVERS:

- Lightning counts in three range categories: Caution (<20 miles), Warning (<10 miles) and Alarm (<5 miles)
- User-defined e-mail notification for lightning and all-clear conditions
- User-set audible and visual alarms
- System state indicators
- Lightning data logging
- Lightning data histogram
- Countdown to "No Lightning Detected"
- Lightning-proof fiber-optic link between Lightning Data Receiver and PC
- Network (LAN) option available

### SOFTWARE SPECIFICATIONS:

COMPUTER REQUIREMENTS: 64MB; Pentium I or higher recommended  
PLATFORM: Windows® 98/ME/2000/XP  
INTERFACE: Strike Guard RS-232 to Fiber-optic Converter to PC's 9-pin serial port or USB Port  
CABLE: Rugged, connector-less PCS PMMA fiber-optic cable  
FORMAT: Installation CD

Contact us today to receive a Strike View Demonstration CD.

**LIGHTNING & SURGE TECHNOLOGIES**  
[www.lightningman.com.au](http://www.lightningman.com.au)